OLIGHT

EN LA CAJA

MANUAL DE USUARIO

Perun 3 Mini Premium

Tabla 2 :

Cargador inalámbrico

Dimensiones	76*38*14mm / 2.99*1.50*0.54in
Peso	145 g / 5.07 oz
Especificaciones	5W/7.5W/10W (18.5W)
Entrada micro	5V⎓2A (9V⎓2A)
Entrada USB	5V⎓2.4 (9V⎓2)
Salida Qi	5 V ⎓ 2.4(9V)
Eficiencia máxima	4.2 V / 1 A
Tiempo de carga total	1 h

Cable de carga USB-C

Tipo de cable	USB-C
Longitud del cable	0.6 m
Color	0.1 / 0.4
Tiempo de carga (Cargador inalámbrico)	2.5 h (Recarga a 5V 2A, 7.5W) when source. When the power source capacity is insufficient, the charging time will be longer.



1 Resumen del producto

2 Retirar la película aislante antes de usar

3 Cargar el cargador

4 Cargar la linterna con el cargador

5 Cargue dispositivos externos con el cargador

Instrucciones de funcionamiento del cargador inalámbrico

6 Encenderlapagar la linterna

7 Modo de bloqueo

8 Luz de Luna

9 Turbo

10 Cambiar nivel de brillo

11 Función de apagado automático

INSTRUCCIONES PARA EL MODO DE LUZ ROJA

12 Encender la linterna

13 Cambiar el modo de iluminación

14 Apagar la linterna

15 Indicador de batería

16 Indicador de la batería (modo Luz de Luna)

17 Fijar la linterna a la cinta para la cabeza

18 Encendiendapagar la linterna con el cargador

19 Cerrar la tapa para apagar la luz

20 Cambia el brillo de la linterna con el cargador.

21 Indicador de batería baja

CONTENTS

[EN] English 3
[CH] 简体中文 5
[FI] Finnish 7
[NO] Norwegian 9
[NL] Nederlands 11
[DE] Deutsch 13
[HU] Magyarország 15
[RU] Русский 17
[ES] Español 19
[RO] Romanesc 21
[UA] Українська 23
[JP] 日本語 25
[KR] 한국어 27
[TH] ไทย 29
[FR] Français 31
[IT] Italiano 33
[SK] Slovenskýjazyk 35
[PT] Português 37

[EN] English

HOW TO CONTENTS

1. Product specifications, see Table 1 and Table 2.
2. Product overview, see Page 1.
3. Product instructions are below:
4. Remove Rechargeable Battery Insulation Film, see Page 2.

Open the wireless charger and remove the insulating film between the charger and the flashlight. Then unscrew the flashlight body to remove the insulating film inside.

3. Charging: ：

3.1 Charge the flashlight with charger, see Page 3.

Gently charging the flashlight on the charger, ensure the charger is connected to a power source before turning off.

3.2 Charge external devices with the charger, see Page 5.

Place the flashlight on the charger and charge the devices once they are connected to the charger. The charging time varies with the battery capacity of the connected device. If the battery level of the connected device is insufficient, the charging time will be extended.

Caution: The display further will turn off.

4. Flashlight Operation：

4.1 Instructions for white light mode:

4.1.1 Turn On/Off the Flashlight, see Page5.

Press the button to turn on/off the flashlight. When turned on, the flashlight will light up at the minimum brightness level. (Turbo will be memorized as high, high will be memorized as Medium if the interval is over 1 minute.)

4.1.2 Cycle mode, see Page 5.

When the flashlight is on, quickly double-press the button to enter Turbo. If pressed twice within 1 second, the flashlight will switch to Turbo. If the previous brightness level was high, the flashlight will switch to Medium.)

4.1.3 Change brightness level, see Page5.

When the flashlight is on, press and hold the button. The Flashlight will cycle through Low-Medium-High (Memorizes and Turbo are not in the cycle). Release the button to select the desired brightness level.

4.1.4 Lock Mode, see Page5.

When the flashlight is on, quickly double-press the button to enter Turbo. Quickly triple-press the button to enter the lockout mode. If the previous brightness level was high, the flashlight will switch to Medium.)

4.1.5 Change brightness level, see Page5.

When the flashlight is on, press and hold the button. The Flashlight will cycle through Low-Medium-High (Memorizes and Turbo are not in the cycle). Release the button to select the desired brightness level.

4.1.6 Turn Off Function, see Page5.

Gently press the button to turn off the flashlight. If the flashlight is locked, press and hold the button when the flashlight is on. After the function is turned on, the light will flash once to indicate that the shut-down period (3 minutes) is set, and twice for the long period (6 minutes). A switch between timing periods. Double-press and hold the button during a timing period. When switching to the Auto Shut-Off function, the previous timing setting will be used.

4.2 Instructions for red light mode:

4.2.1 Access thermal lightmode, see Page5.

When the flashlight is off, double-press the button to access red light mode.

4.2.2 Change lighting mode,see Page5.

Press and hold the button to switch between Low, Low mode, High mode, and SOS mode.

4.2.3 Cutting-edge mode,see Page5.

When the flashlight is on, quickly triple-press the button to turn it off.

4.2.4 Lock mode, see Page5.

5. Battery indicator：1 When turn on the flashlight mode, see Page 10. 2 In the Moonlight mode, see Page 10. 3 Battery indicator, see Page 10. 4 Battery indicator in the Moonlight mode, see Page 10. 5 Battery indicator：1 When turn on the flashlight mode, see Page 10. 2 In the Moonlight mode, see Page 10. 3